


# barbas .

## User manual

BOX 40-55-110



This product is not suitable for primary heating purposes



Serial number:

Production date:

**© Barbas Bellfires BV**

This document or parts thereof may not be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, nor otherwise, without the prior written permission of Barbas Bellfires BV. This document could contain technical inaccuracies or typographical errors. Barbas Bellfires BV reserves the right to revise this document from time to time in the contents thereof.

**Contact information**

Barbas Bellfires BV

Hallenstraat 17, 5531 AB Bladel, The Netherlands

E-mail: [info@barbas.com](mailto:info@barbas.com)

[www.barbas.com](http://www.barbas.com)

## Contents

|           |                                                              |           |
|-----------|--------------------------------------------------------------|-----------|
| <b>1</b>  | <b>Declaration of performance BOX 40-55-110.....</b>         | <b>5</b>  |
| <b>2</b>  | <b>About this document.....</b>                              | <b>6</b>  |
| 2.1       | How to work with this document.....                          | 6         |
| 2.2       | Warnings and cautions used in this document.....             | 6         |
| 2.3       | Related documentation.....                                   | 6         |
| <b>3</b>  | <b>Description.....</b>                                      | <b>7</b>  |
| 3.1       | Overview of the front of the appliance.....                  | 7         |
| 3.2       | Intended use.....                                            | 8         |
| <b>4</b>  | <b>Safety.....</b>                                           | <b>9</b>  |
| 4.1       | Safety instructions for operation.....                       | 9         |
| 4.2       | Safety instructions with regard to the environment.....      | 10        |
| <b>5</b>  | <b>Fuel.....</b>                                             | <b>11</b> |
| 5.1       | Fuel types.....                                              | 11        |
| 5.2       | Fuel amount.....                                             | 11        |
| <b>6</b>  | <b>Operation.....</b>                                        | <b>13</b> |
| 6.1       | Preparation before first use.....                            | 13        |
| 6.2       | First use of the appliance.....                              | 13        |
| 6.3       | Firing the appliance.....                                    | 13        |
| 6.3.1     | First load and ignition.....                                 | 13        |
| 6.3.2     | Reload for nominal heat output.....                          | 15        |
| 6.3.3     | Reload for minimum heat output.....                          | 15        |
| 6.3.4     | Control the burn process .....                               | 16        |
| 6.3.5     | Increase the flue draught .....                              | 17        |
| 6.3.6     | General firing tips.....                                     | 19        |
| <b>7</b>  | <b>Maintenance.....</b>                                      | <b>20</b> |
| 7.1       | Maintenance schedule.....                                    | 20        |
| 7.2       | Remove the ashes.....                                        | 20        |
| 7.3       | Clean the glass.....                                         | 20        |
| <b>8</b>  | <b>Troubleshooting.....</b>                                  | <b>21</b> |
| <b>9</b>  | <b>Information on disposal of the appliance .....</b>        | <b>23</b> |
| <b>10</b> | <b>Technical data.....</b>                                   | <b>24</b> |
| 10.1      | Technical data .....                                         | 24        |
| 10.2      | Product information according regulation (EU) 2015/1185..... | 26        |

11    Warranty Terms..... 27

1

## Declaration of performance BOX 40-55-110

**barbas bellfires .**  
Crafted to wonder

| EU-declaration of conformity                                                                                                                                                                                                                                                                              |  |                                                                       |                          |              |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|-----------------------------------------------------------------------|--------------------------|--------------|
| This EC declaration of conformity applies to the product described below and describes the conformity with the following directives:<br><b>2009/125/EC Directive for the setting of eco-design requirements for energy-related products (eco-design directive)</b><br>Relevant Regulation: (EU) 2015/1185 |  |                                                                       |                          |              |
| Declaration of Performance                                                                                                                                                                                                                                                                                |  |                                                                       |                          |              |
| No. 2.203.080-0 - CPR-2013/07/01                                                                                                                                                                                                                                                                          |  |                                                                       |                          |              |
| Unique identification code of the product type:                                                                                                                                                                                                                                                           |  | BOX 40-55-110                                                         |                          |              |
| Intended use:                                                                                                                                                                                                                                                                                             |  | Space heating in residential buildings                                |                          |              |
| Manufacturer:                                                                                                                                                                                                                                                                                             |  | Barbas Bellfires BV; Hallenstraat 17; 5531 AB Bladel; The Netherlands |                          |              |
| System of AVCP:                                                                                                                                                                                                                                                                                           |  | 3                                                                     |                          |              |
| Harmonised technical specifications:                                                                                                                                                                                                                                                                      |  | EN 16510-2-1:2022                                                     |                          |              |
| Notified body:                                                                                                                                                                                                                                                                                            |  | No. 1639                                                              |                          |              |
| Essential characteristics                                                                                                                                                                                                                                                                                 |  |                                                                       |                          |              |
| Mechanical resistance and stability                                                                                                                                                                                                                                                                       |  |                                                                       |                          |              |
| Load bearing capacity                                                                                                                                                                                                                                                                                     |  | 120 kg                                                                |                          |              |
| Safety in case of fire - Protection of combustible materials                                                                                                                                                                                                                                              |  | Minimum distance to combustible materials                             |                          |              |
| Bottom (d <sub>b</sub> ):                                                                                                                                                                                                                                                                                 |  | 3 cm                                                                  |                          |              |
| Floor in front (d <sub>f</sub> ):                                                                                                                                                                                                                                                                         |  | 20 cm                                                                 |                          |              |
| Ceiling (d <sub>c</sub> ):                                                                                                                                                                                                                                                                                |  | 50 cm                                                                 |                          |              |
| Rear (d <sub>a</sub> ):                                                                                                                                                                                                                                                                                   |  | 25 cm                                                                 |                          |              |
| Side (d <sub>s</sub> ):                                                                                                                                                                                                                                                                                   |  | 20 cm                                                                 |                          |              |
| Side radiation area (d <sub>r</sub> ):                                                                                                                                                                                                                                                                    |  | 50 cm                                                                 |                          |              |
| Front (d <sub>p</sub> ):                                                                                                                                                                                                                                                                                  |  | 140 cm                                                                |                          |              |
| Hygiene, health and the environment                                                                                                                                                                                                                                                                       |  |                                                                       |                          |              |
|                                                                                                                                                                                                                                                                                                           |  | At nominal heat output                                                | At part load heat output |              |
| Carbon monoxide emission (CO)                                                                                                                                                                                                                                                                             |  | 1068 mg/m <sup>3</sup>                                                | 2909 mg/m <sup>3</sup>   |              |
| Nitrogen oxides emission (NO <sub>x</sub> )                                                                                                                                                                                                                                                               |  | 96 mg/m <sup>3</sup>                                                  | 109 mg/m <sup>3</sup>    |              |
| Emission of organic gaseous carbon (OGC)                                                                                                                                                                                                                                                                  |  | 89 mg/m <sup>3</sup>                                                  | 466 mg/m <sup>3</sup>    |              |
| Particulate matter emission (PM)                                                                                                                                                                                                                                                                          |  | 23 mg/m <sup>3</sup>                                                  | 56 mg/m <sup>3</sup>     |              |
| Safety and accessibility in use                                                                                                                                                                                                                                                                           |  | Data for installation to a chimney                                    |                          |              |
|                                                                                                                                                                                                                                                                                                           |  | At nominal heat output                                                | At part load heat output |              |
| Flue gas outlet temperature                                                                                                                                                                                                                                                                               |  | 322 °C                                                                | 259 °C                   |              |
| Minimum flue draught                                                                                                                                                                                                                                                                                      |  | 12 Pa                                                                 | 8 Pa                     |              |
| Flue gas mass flow                                                                                                                                                                                                                                                                                        |  | 8.7 g/s                                                               | 7.8 g/s                  |              |
| Fire safety of installation to the chimney                                                                                                                                                                                                                                                                |  | T400 G minimum                                                        |                          |              |
| Energy economy and heat retention                                                                                                                                                                                                                                                                         |  | Appliance's thermal heat output and energy efficiency                 |                          |              |
|                                                                                                                                                                                                                                                                                                           |  | At nominal heat output                                                | At part load heat output |              |
| Space heat output                                                                                                                                                                                                                                                                                         |  | 7.3 kW                                                                | 4.4 kW                   |              |
| Efficiency                                                                                                                                                                                                                                                                                                |  | 76.3 %                                                                | 69.8 %                   |              |
| Seasonal space heating efficiency                                                                                                                                                                                                                                                                         |  | 66.3 %                                                                | Space heating efficiency |              |
| Energy efficiency index (EEI)                                                                                                                                                                                                                                                                             |  | 101                                                                   |                          |              |
| Energy efficiency class                                                                                                                                                                                                                                                                                   |  | A                                                                     |                          |              |
|                                                                                                                                                                                                                                                                                                           |  | At nominal heat output                                                | At part load heat output | Standby mode |
| Electric power consumption                                                                                                                                                                                                                                                                                |  | N/A                                                                   | N/A                      | N/A          |
| Sustainable use of natural resources                                                                                                                                                                                                                                                                      |  | Environmental sustainability                                          |                          |              |
|                                                                                                                                                                                                                                                                                                           |  | NPD                                                                   |                          |              |
| The performance of the product identified above is in conformity with the set of declared performances. This declaration of performance is issued, in accordance with Regulation (EU) No 305/2011, under the sole responsibility of the manufacturer identified above.                                    |  |                                                                       |                          |              |
| Signed for and on behalf of the manufacturer by:                                                                                                                                                                                                                                                          |  |                                                                       |                          |              |
| Danny Baijens, CEO                                                                                                                                                                                                                                                                                        |  |                                                                       |                          |              |
|                                                                                                                                                                                                                        |  |                                                                       |                          |              |
| Bladel, The Netherlands<br>25 August 2025                                                                                                                                                                                                                                                                 |  |                                                                       |                          |              |

## 2 About this document

This document shows the necessary information to do these tasks on the BOX 40-55-110:

- Operate the appliance
- Do basic maintenance

This document refers to the BOX 40-55-110 as 'the appliance'. This document is an essential part of your appliance. Read it carefully before you do work on the appliance. Keep it in a safe place.

The original instructions of the document are in English. All other language versions of the document are translations of the original instructions. It is not always possible to provide a detailed illustration of every single item of the equipment. The illustrations in this document show a typical setup. The illustrations are for instructional use only.

### 2.1 How to work with this document

1. Make yourself familiar with the structure and content of the document.
2. Read the safety section in detail.
3. Make sure that you understand all the instructions.
4. Do the procedures completely and in the given sequence.

### 2.2 Warnings and cautions used in this document

#### Warning

If you do not obey these instructions, there is a risk that can cause personal injury or death.

#### Caution

If you do not obey these instructions, there is a risk of damage to the appliance, installation or to property.

#### Note

A note shows more information.


| Symbol                                                                              | Description                        |
|-------------------------------------------------------------------------------------|------------------------------------|
|  | Visual sign that there is a hazard |
|  | Visual sign that there is a notice |

### 2.3 Related documentation

- Installation and maintenance manual
- User manual

## 3 Description

### 3.1 Overview of the front of the appliance



- |   |                     |   |                            |
|---|---------------------|---|----------------------------|
| A | Door handle         | F | Log guard                  |
| B | Glass               | G | Ash tray (under the grate) |
| C | Primary air inlet   | H | Combustion chamber panels  |
| D | Grate               | I | Flue connection            |
| E | Steel bottom plates | J | Control lever              |

## 3.2 Intended use

The appliance is intended for indoor use to heat the room wherein it is installed. Do not use it for other purposes.

It is not allowed to use the appliance as primary heating appliance.

The appliance is intended for use with wood logs or wood briquettes as fuel. Do not use other fuels and waste.

The appliance is intended for use with the door closed.

The appliance may only be used at the location that meets the requirements for the installation of the appliance.

The appliance is intended for intermittent use and is not intended for continuous use.

It is not allowed to connect the appliance on a shared flue gas channel.

The appliance is intended to heat the room by direct heating. It is not allowed to connect the appliance to a central-heating installation.



## 4 Safety

### 4.1 Safety instructions for operation

**Warning:**

- Do not put objects on the top of the appliance.
- Do not let the appliance unattended when the fuel burns.
- Do not put flammable items within 140 cm from the front of the appliance.
- Do not put flammable items within 20 cm from the side of the appliance.
- If applicable, make sure the distance between the top of the wood log storage module and the wood logs in the storage module is minimum 10 cm. Make sure the wood logs in the storage do not touch the top of the wood log storage module.
- Do not use mineral fuel (example: coal, anthracite)
- Do not use liquid fuels.
- Do not use gasoline-type lantern fuel, kerosene, gasoline, kerosene, charcoal lighter fluid, alcohol, or similar liquids to start or re-ignite a fire in the appliance. Make sure to keep these liquids away from the appliance.
- Do not use the appliance with the door open. Smoke can escape from the appliance. Only open the appliance door for a short time to reload with fuel or to remove the ash.
- Make sure that children are supervised when they can reach the appliance.
- Make sure that there is sufficient ventilation in the room in which the appliance is installed.
- Do not use the appliance in case of visual glass damage.
- Do not use the appliance in case of damage of the door gaskets
- Make sure that the appliance is installed correctly. Refer to the Installation and Maintenance manual. You can find the manuals on [www.barbasbellfires.com](http://www.barbasbellfires.com).
- The simultaneous use of an extractor fan (e.g. a cooker hood), can cause smoke escape from the appliance, when the appliance door is open.
- Wear the glove and use the operating hook or a poke when refilling the appliance
- Make sure that your clothing does not touch the appliance. Especially synthetic clothing ignites easy and burns intensely.
- Do not use the appliance when there is fog, haze or no wind.
- Do not make modifications to the appliance. Any modification will also make your warranty invalid.

**Caution:**

- Make sure to clean your chimney minimum every year to prevent a chimney fire.
- Do not use freshly cut wood.
- Do not use more wood per load than prescribed. Refer to section 5.2 for the recommended fuel amount.
- Do not burn waste in the appliance.
- Do not prepare food in the appliance. This causes damage to your appliance and chimney.

**Note:**

- Do inspect and clean the appliance, the chimney and the external combustion air supply by a Barbas dealer minimum every year.
- Do not use the appliance continuously. The intended use is as intermittent appliance.

**4.2****Safety instructions with regard to the environment**

- Dispose of the packing materials in an environmentally friendly way.
- Dispose of ceramic heat-resistant glass as household waste. Do not dispose of ceramic heat-resistant glass in a glass recycling container.
- Dispose of an obsolete appliance according to instructions of the authorities or the fitter.
- Obey the local regulations.

## 5 Fuel

### 5.1 Fuel types



**Warning:**

Do not use coal, anthracite, coal briquettes, liquid fuel or gel fuel. The appliance is not designed for these fuels. Use of these fuels is dangerous and can lead to bodily harm and to serious damage to the appliance.

Suitable fuels are:

- Hard wood (example: birch, beech, oak, ash).
- Soft wood (example: spruce, pine, poplar).
- Wood briquettes without binder.

Before use, wood must dry for minimum 2 years when freshly chopped. Kiln-dried wood must dry for an extra half year. Dried wood logs must have a moisture content of 10 - 20 %.

Unsuitable fuels are:

- Painted wood.
- Impregnated wood.
- MDF, chipboard.
- Any kind of combustible waste.
- Paraffin impregnated compressed wood logs
- Freshly chopped wood
- Coal, anthracite and other bituminous fuels
- Lignite, peat

Using unsuitable fuels cause excess smoke, black glass, combustible deposits in the chimney and can damage the appliance.

### 5.2 Fuel amount

Load the appliance with the amount of fuel as listed hereunder. Put the load as one layer on the floor of the combustion chamber. For the amount of fuel for the first load see chapter [6.3.1](#).



**Caution:**

The amount of fuel specified for the nominal heat output should not be exceeded, overloading can cause excess smoke.

**Fuel load for nominal heat output**

|        | Wood logs                      | Wood briquettes                |
|--------|--------------------------------|--------------------------------|
| Amount | 2 pieces                       | 2 pieces                       |
| Weight | Approximately 0.8 kg per piece | Approximately 0.7 kg per piece |
| Length | Approximately 30 cm            | Approximately 30 cm            |

**Fuel load for minimum heat output**

|        | Wood logs                      | Wood briquettes                |
|--------|--------------------------------|--------------------------------|
| Amount | 1 piece                        | 1 piece                        |
| Weight | Approximately 1.0 kg per piece | Approximately 0.9 kg per piece |
| Length | Approximately 25 cm            | Approximately 25 cm            |

The above listed amount burns for approximately 45 minutes. This time can be different, dependent on the chimney draught and the position of the combustion air valve.

## 6 Operation

### 6.1 Preparation before first use

Report any defects to your dealer immediately.

#### Procedure

1. Make sure that the appliance is not damaged.
2. Make sure that the ceramic plate and the baffles are in the correct position.
3. Make sure that the glass is not damaged.
4. Make sure that the door opens and closes completely, by moving the door handle
5. Remove document and components from the combustion chamber.
6. Make sure that the control lever moves easy.
7. Make sure that the ash tray is empty.
8. Make sure that all package material, stickers, etc, have been removed from the vicinity of the appliance after installation.

### 6.2 First use of the appliance



#### Caution:

Make sure there is sufficient ventilation in the room in which the appliance is installed.



#### Note:

The appliance has a heat-resistant coating. When you use the appliance for the first time, the coating can cause an unpleasant, but harmless smell.

After first few times of use of the appliance, a light deposit on the inside of the glass may occur caused by curing of the paint. This can be removed with glass cleaner or ceramic hob cleaner.

### 6.3 Firing the appliance

#### 6.3.1 First load and ignition




#### Warning:

Do not use the appliance when there is fog or haze or no wind.


At the beginning the appliance and chimney are cold. It is important that both the appliance and chimney reach a temperature that guarantees a good functioning of the appliance. A too low temperature results in incomplete combustion and a poor chimney draught. To avoid this do the following:

1. Put the control lever in the far right position.
2. If applicable, open the valve in the external combustion air supply line.
3. If applicable, open the chimney valve completely.
4. Open the door of the appliance.


5. Put minimum 4 wood logs crosswise on the floor of the combustion chamber.



6. Put some kindling wood and 1 or 2 firestarter cubes on top of the wood logs.



7. Put some kindling wood above the firestarter cubes.



8. Light the firestarter cubes with a lighter or a match.
9. Close the door of the appliance.

After approximately 20 minutes the wood logs burn. Dependent on the quality of the chimney the wood logs burn for approximately 1 to 1.5 hours. Do not open the door of the appliance before the last flames have almost disappeared.

## 6.3.2 Reload for nominal heat output



### Caution:


If there is insufficient burning material in the firebed to light a new fuel charge, excessive smoke emission can occur. Refueling must be done onto a sufficient quantity of glowing embers and ash to make sure that the new fuel charge will ignite in a reasonable period. If there are too few embers in the fire bed, add suitable kindling to prevent excessive smoke.



### Note:

The procedure hereunder is a general description to fire with nominal heat output. The best reloading moment is dependent on the flue draught. A high flue draught requires reloading when the flames have completely disappeared. If the flue draught is low, reloading must be done when there are still flames.

1. Wait until the last flames have almost disappeared.
2. Set the control lever in the far right position.
3. Open the door.
4. Reload the appliance with 2 wood logs or 2 wood briquettes. Refer to section 5.2 for the weight and length of the wood logs.



5. Close the door.
6. After ignition of the fuel, move the control lever to a position that gives a quiet burning fire.

## 6.3.3 Reload for minimum heat output



### Caution:

If there is insufficient burning material in the firebed to light a new fuel charge, excessive smoke emission can occur. Refueling must be done onto a sufficient quantity of glowing embers and ash to make sure that the new fuel charge will ignite in a reasonable period. If there are too few embers in the fire bed, add suitable kindling to prevent excessive smoke.




### Note:

The procedure hereunder is a general description to fire with minimum heat output. The best reloading moment is dependent on the flue draught. A high flue draught requires reloading when the flames have completely disappeared. If the flue draught is low, reloading must be done when there are still flames.

1. Wait until the last flames have almost disappeared.
2. Set the control lever in the far right position.

3. Open the door.
4. Reload the appliance with 1 wood log or 1 wood briquette. Refer to section [5.2](#) for the weight and the length of the wood log.



5. Close the door.
6. After ignition of the fuel, move the control lever to a position that gives a quiet burning fire.

### 6.3.4

#### Control the burn process

Control the burn process with the control lever. This lever controls the amount of primary combustion air and both the secondary combustion air and airwash amount.



**Warning:**


Setting the control lever in the far left position (all air inlets closed) when the fuel is burning leads to excessive emission of hazardous gasses (example: carbon monoxide) and soot deposit on the glass of the door and in the chimney. Never close the air inlets when the fuel is burning. Always keep the secondary air inlet and air wash inlet open by setting the control lever somewhere in-between the center position and the far left position.



**Caution:**

Continuous firing with the primary air inlet fully open (control lever in the far right position) causes a white-hot fire that can damage the appliance. Use the primary air only during the first fuel load and for ignition of a new fuel load.





## 6.3.5


### Increase the flue draught




**Warning:** Do the procedure hereunder when you have made sure the appliance has cooled down and there are no glowing embers.

A low flue draught is caused by too much flow resistance. This causes insufficient flow of the flue gas in the chimney. Do the next steps to decrease the flow resistance


1. Open the door.
2. Loosen the nut above the heat shield with a 3 mm hexagonal key and a 10 mm fork spanner. Turn the nut down with the fork spanner and turn the screw up with the hexagonal key until the screw is loose from the heat shield.




3. Push up the front of the heat shield (1) and pull it forward (2) and move downward to a vertical position (3).
4. Remove the heat shield from the appliance.




5. Remove the break strip from the baffle with a pair of pliers.



6. Move the heat shield up and put the rear side above the baffle (1).
7. Move the front of the heat shield up (2) and put the edge on the metal strip under the air wash inlet (3).



8. Turn the screw down with a 3 mm hexagonal key until it is in the screw hole in the heat shield.
9. Turn the nut up with a 10 mm fork spanner and tighten it.



## 6.3.6

### General firing tips

- The appliance works best when it has been heated up as described in section [6.3.1](#). Insufficient heating up leads to a low chimney draught, black deposits on the glass and incomplete combustion. Good combustion is recognized by bright orange flames, invisible smoke and no soot deposits on the glass. Use the control lever to get good combustion. Refer to section [5.1](#) for advice on the required fuel quality.
- Make sure the door of the appliance is closed when in use. Only open the door for ignition and to refuel.
- Do not remove all the ashes. An ash layer in the combustion chamber forms a heat insulating layer, that helps the fuel to ignite easy.
- Do not set the control lever in the far left position (all combustion air inlets closed) when the appliance is used. This will cause severe smoke development, soot formation and increases the chance of a chimney fire.
- After the first load, do not overload the appliance with fuel. Refer to section [5.2](#) for the recommended amount of fuel. Too much fuel leads to incomplete combustion, soot formation and a chance of a chimney fire.
- When the appliance is not in use and completely cooled down, put the control lever in the far left position to close the combustion air supply.

## 7 Maintenance

### 7.1 Maintenance schedule



**Caution:**

Clean the glass when it is dirty. If the glass is not cleaned when it is dirty the glass can become permanently dull.

| Task                       | Frequency                             | Procedure                                        |
|----------------------------|---------------------------------------|--------------------------------------------------|
| Remove the ashes           | When necessary                        | Refer to section <a href="#">7.2</a>             |
| Clean the glass            | When necessary                        | Refer to section <a href="#">7.3</a>             |
| Maintenance by your fitter | Yearly                                | Refer to your dealer                             |
| Chimney sweep              | Yearly (or more often when necessary) | Refer to the Installation and maintenance manual |
| Appliance inspection       | Yearly                                | Refer to the Installation and maintenance manual |

### 7.2 Remove the ashes

1. Make sure that the appliance has cooled down and there are no glowing embers.
2. Remove the ashes with a small scoop.
3. Lift the grate with the operating hook and remove the grate.
4. Remove the ashtray and empty it.
5. Make sure there are no ashes in the space under the ash tray. Remove these ashes when necessary.
6. Put the ash tray back in the appliance.
7. Put the grate back in the appliance.

### 7.3 Clean the glass

1. Make sure the appliance has cooled down and there are no glowing embers in the combustion chamber.
2. To avoid any up swirl of ashes during cleaning, remove the ashes from the appliance.
3. Clean the glass with a soft cloth, a sponge or paper. Use glass cleaner or ceramic hob cleaner.
4. Make sure that the glass is dry. Water droplets can leave a mark on the glass.



**Note:**

Damaged or broken glass must be replaced before the appliance can be used again.

## 8 Troubleshooting

| Problem                                                                 | Possible cause                                    | Possible solution                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------|---------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Chimney fire (recognized by a roaring sound in the chimney)             | Ignition of soot and tar deposits in the chimney. | <ul style="list-style-type: none"> <li>Set the control lever in the far left position.</li> <li>Call the emergency services. (112)</li> <li>Put out the fire in the appliance with sand.</li> </ul>  <p><b>Warning:</b><br/>Never use water to put out the fire.</p> <ul style="list-style-type: none"> <li>Ventilate the house.</li> </ul> <p>After the chimney has been extinguished, sweep the chimney and inspect for damage.</p> <p>Sweep the chimney minimum once a year by a certified chimney sweep.</p> |
| The wood logs do not ignite                                             | The moisture content of the wood logs is too high | <ul style="list-style-type: none"> <li>Use dried wood logs with a moisture content of 10 - 20 %.</li> <li>Use wood briquettes</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                                            |
|                                                                         | The combustion chamber is not warm enough         | <ul style="list-style-type: none"> <li>Do the recommended ignition procedure. Refer to section <a href="#">6.3.1</a>.</li> <li>Use the recommended amount of fuel. Refer to section <a href="#">5.2</a>.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                 |
| The wood logs burn too fast                                             | Primary air inlet is open.                        | Close the primary air supply. Adjust the amount of secondary air and air wash with the control lever. Refer to section <a href="#">6.3.4</a> .                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|                                                                         | The chimney draught is too high                   | <ul style="list-style-type: none"> <li>Reduce the amount of secondary air and airwash with the control lever. Refer to section <a href="#">6.3.4</a></li> <li>Contact your installer.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                    |
| The temperature of the room does not rise sufficient                    | The fuel amount is too low                        | Use the recommended amount of fuel. Refer to section <a href="#">5.2</a> .                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                          |
|                                                                         | The chimney draught is too high                   | Contact your installer.                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                             |
| Excessive smoke escapes when the door of the combustion chamber is open | The chimney draught is too low                    | <ul style="list-style-type: none"> <li>Do the recommended ignition procedure. Refer to section <a href="#">6.3.1</a>.</li> <li>Contact your installer.</li> </ul>                                                                                                                                                                                                                                                                                                                                                                                                                                   |

| Problem                                                                                   | Possible cause                                                              | Possible solution                                                                                                                                                                                                                                                                                                                               |
|-------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The glass becomes black                                                                   | The combustion chamber is not hot enough                                    | <ul style="list-style-type: none"> <li>• Use the recommended amount of fuel. Refer to section <a href="#">5.2</a>.</li> <li>• Increase the amount of combustion air with the control lever. Refer to section <a href="#">6.3.4</a>.</li> <li>• Put the wood logs diagonally and as wide as possible on the combustion chamber floor.</li> </ul> |
|                                                                                           | The moisture content of the wood logs is too high                           | <ul style="list-style-type: none"> <li>• Use dried wood logs with a moisture content of 10 - 20 %.</li> <li>• Use wood briquettes</li> </ul>                                                                                                                                                                                                    |
|                                                                                           | The seal around the door is damaged                                         | Contact your dealer.                                                                                                                                                                                                                                                                                                                            |
| Some cold air flows out from the front of the appliance when the appliance is not in use. | The valve in the external combustion air supply line is missing or is open. | Close the valve in the external combustion air supply line.                                                                                                                                                                                                                                                                                     |
|                                                                                           | The underpressure in the installation room is too high                      | Reduce the underpressure, for example by opening a ventilation opening in the installation room.                                                                                                                                                                                                                                                |

## 9 Information on disposal of the appliance

- Dispose of an obsolete appliance according to instructions of the authorities or the installer.
- The information in this section is informative. Always obey the national and local regulations on recycling and disposal of the appliance or parts of the appliance.
- Before disassembly and disposal of the appliance, remove ashes and unburnt fuel from the appliance. Dispose ashes as rest waste. Do not dispose ashes as organic waste.

| Appliance component                   | Material                   | Disassembly                                                                     | Recycling / Disposal                                                                               |
|---------------------------------------|----------------------------|---------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------|
| Combustion chamber (walls)            | Cast iron                  | Refer to the Installation Manual                                                | Dispose as metal waste                                                                             |
| Combustion chamber (walls and baffle) | Vermiculite                | Refer to the Installation Manual                                                | Vermiculite in contact with combustion gases cannot be re-used or recycled. Dispose as rest waste. |
| Combustion chamber (walls and baffle) | Heat resistant ceramic     | Refer to the Installation Manual                                                | Ceramic in contact with combustion gases cannot be re-used or recycled. Dispose as rest waste.     |
| Combustion chamber (grate and bottom) | Steel                      | Refer to the Installation Manual                                                | Dispose as metal waste                                                                             |
| Combustion chamber (Heat shield)      | Steel                      | Refer to the Installation Manual                                                | Dispose as metal waste                                                                             |
| Glass                                 | Ceramic glass              | Remove glass holder with suitable tools. Remove gaskets and cord from the glass | Dispose as rest waste or ceramic waste. Do not dispose as glass waste.                             |
| Appliance body                        | Steel                      | Make sure to remove all components other than metal                             | Dispose as metal waste                                                                             |
| Ash tray                              | Steel                      | Remove from appliance                                                           | Dispose as metal waste                                                                             |
| Gaskets                               | Glass fibre cord or plates | Remove from appliance and components                                            | Dispose as glass fibre (non-flammable waste)                                                       |
| Stone base                            | Natural stone              | Remove from appliance                                                           | Dispose as building construction waste (stone)                                                     |

## 10 Technical data

### 10.1 Technical data

|                                                           |                                                                                      |                                 |
|-----------------------------------------------------------|--------------------------------------------------------------------------------------|---------------------------------|
| Name                                                      | Barbas                                                                               |                                 |
| Model                                                     | BOX 40-55-110                                                                        |                                 |
| EPREL registration number                                 | 2109701                                                                              |                                 |
| Tested in accordance with                                 | EN16510-2-1                                                                          |                                 |
| Energy efficiency index                                   | 101                                                                                  |                                 |
| Energy efficiency class                                   | A                                                                                    |                                 |
| Fuel                                                      | Wood logs, Wood briquettes                                                           |                                 |
| Indirect heating function                                 | No                                                                                   |                                 |
| Room sealed                                               | No                                                                                   |                                 |
| Leak rate at 10 Pa                                        | not applicable                                                                       |                                 |
| Seasonal efficiency                                       | 66.3 %                                                                               |                                 |
|                                                           | <b>At nominal heat output</b>                                                        | <b>At part load heat output</b> |
| Fuel load                                                 | 1.6 kg                                                                               | 1.1 kg                          |
| Heat output (net)                                         | 7.3 kW                                                                               | 4.4 kW                          |
| Useful efficiency                                         | 76.3 %                                                                               | 69.8 %                          |
| <b>Emissions (at 13 % O<sub>2</sub>, 273 K, 1013 hPa)</b> |                                                                                      |                                 |
| • carbon monoxide (CO)                                    | 1068 mg/Nm <sup>3</sup>                                                              | 2909 mg/Nm <sup>3</sup>         |
| • particles (PM)                                          | 23 mg/Nm <sup>3</sup>                                                                | 56 mg/Nm <sup>3</sup>           |
| • organic gaseous compounds (OGC)                         | 89 mg/Nm <sup>3</sup>                                                                | 466 mg/Nm <sup>3</sup>          |
| • nitrogen oxides (NO <sub>x</sub> )                      | 96 mg/Nm <sup>3</sup>                                                                | 109 mg/Nm <sup>3</sup>          |
| Flue gas mass flow                                        | 8.7 g/s                                                                              | 7.8 g/s                         |
| Flue gas outlet temperature                               | 322 °C                                                                               | 259 °C                          |
| Flue gas temperature                                      | 268 °C                                                                               | 216 °C                          |
| Minimum chimney draught                                   | 12 Pa                                                                                | 8 Pa                            |
| Minimum temperature class of the chimney                  | T 400                                                                                |                                 |
| Flue gas connection                                       | Outer diameter 128 mm, suitable for a pipe with an inner diameter of 130 mm          |                                 |
| External combustion air connection                        | 80 mm                                                                                |                                 |
| Weight with vermiculite interior                          | 215 kg                                                                               |                                 |
| Weight with ceramic interior                              | 226 kg                                                                               |                                 |
| Minimum distance to flammable materials                   | Refer to the installation and maintenance manual                                     |                                 |
| <b>Used materials</b>                                     |                                                                                      |                                 |
| Combustion chamber side and back panels                   | Heat resistant ceramic 1600 kg/m <sup>3</sup> / Vermiculite 750 kg/m <sup>3</sup> *) |                                 |
| Combustion floor and grate                                | Steel                                                                                |                                 |



|                                                                                                                                                       |                                                                                                                |
|-------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|
| Baffle                                                                                                                                                | Heat resistant ceramic 1600 kg/m <sup>3</sup> / Vermiculite 750 kg/m <sup>3</sup> *)                           |
| Heat shield                                                                                                                                           | Steel                                                                                                          |
| Front glass                                                                                                                                           | Heat resistant ceramic glass                                                                                   |
| The specific precautions that shall be taken when the local space heater is assembled, installed or maintained, are listed in the attached documents: | <ul style="list-style-type: none"> <li>• Installation and maintenance manual</li> <li>• User manual</li> </ul> |
| Maximum capacity to carry a chimney                                                                                                                   | 120 kg *)                                                                                                      |

| Additional information in order to achieve relevant test results for market surveillance |                        |
|------------------------------------------------------------------------------------------|------------------------|
| Mass of basic fire bed                                                                   | 120 g                  |
| Criterion for the end of the test cycle                                                  | 5 vol% CO <sub>2</sub> |

\*) Type of material is dependent on the choice made at the time of purchase.

\*\*) if the weight of the chimney or part of the chimney, being carried by the appliance, is more than indicated, the chimney must be supported with a wall bracket.

## 10.2 Product information according regulation (EU) 2015/1185

| Model identifier                                                                                                                                                                            | BOX 35-55-120                                                               |                        |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------|------------------------|------------------------------------------------------------------------------------|------------------------------------------------------------------|------------------|-----------------|-------------------------------------------------------------------------------------|------|--------|-----------------|------|--|--|--|
| Equivalent models                                                                                                                                                                           | BOX 40-55-110                                                               |                        |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Indirect heating function                                                                                                                                                                   | No                                                                          |                        |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Direct heat output                                                                                                                                                                          | 7.3 kW                                                                      |                        |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Indirect heat output                                                                                                                                                                        | - kW                                                                        |                        |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Fuel                                                                                                                                                                                        | Preferred fuel (only one)                                                   | Other suitable fuel(s) | Emissions at nominal heat output (*)<br>[mg/Nm <sup>3</sup> (13 % O <sub>2</sub> ) |                                                                  |                  |                 | Emissions at minimum heat output (**)<br>[mg/Nm <sup>3</sup> (13 % O <sub>2</sub> ) |      |        |                 |      |  |  |  |
|                                                                                                                                                                                             |                                                                             |                        | PM                                                                                 | OGC                                                              | CO               | NO <sub>x</sub> | PM                                                                                  | OGC  | CO     | NO <sub>x</sub> |      |  |  |  |
| Wood logs, moisture content < 25 %                                                                                                                                                          | yes                                                                         | no                     | ≤ 40                                                                               | ≤ 120                                                            | ≤ 1500           | ≤ 200           | N.A.                                                                                | N.A. | N.A.   | N.A.            |      |  |  |  |
| Compressed wood, moisture content < 12 %                                                                                                                                                    | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Other woody biomass                                                                                                                                                                         | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Non-woody biomass                                                                                                                                                                           | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Anthracite and dry steam coal                                                                                                                                                               | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Hard coke                                                                                                                                                                                   | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Low temperature coke                                                                                                                                                                        | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Bituminous coal                                                                                                                                                                             | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Lignite briquettes                                                                                                                                                                          | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Peat briquettes                                                                                                                                                                             | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Blended fossil fuel briquettes                                                                                                                                                              | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Other fossil fuel                                                                                                                                                                           | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Blended biomass and fossil fuel briquettes                                                                                                                                                  | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Other blend of biomass and solid fuel                                                                                                                                                       | no                                                                          | no                     |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| <b>Characteristics when operating with the preferred fuel</b>                                                                                                                               |                                                                             |                        |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Seasonal space heating efficiency $\eta_{se}$ [%]                                                                                                                                           | 66                                                                          |                        |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Energy efficiency index (EEI)                                                                                                                                                               | 101                                                                         |                        |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Item                                                                                                                                                                                        | Symbol                                                                      | Value                  | Unit                                                                               | Item                                                             | Symbol           | Value           | Unit                                                                                | Item | Symbol | Value           | Unit |  |  |  |
| <b>Heat output</b>                                                                                                                                                                          |                                                                             |                        |                                                                                    | <b>Useful efficiency (NCV as received)</b>                       |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Nominal heat output                                                                                                                                                                         | P <sub>nom</sub>                                                            | 7.3                    | kW                                                                                 | Useful efficiency at nominal heat output                         | $\eta_{th, nom}$ | 76.3            | %                                                                                   |      |        |                 |      |  |  |  |
| Minimum heat output (indicative)                                                                                                                                                            | P <sub>min</sub>                                                            | 4.4                    | kW                                                                                 | Useful efficiency at minimum heat output (indicative)            | $\eta_{th, min}$ | 69.8            | %                                                                                   |      |        |                 |      |  |  |  |
| <b>Auxiliary power consumption</b>                                                                                                                                                          |                                                                             |                        |                                                                                    | <b>Type of heat output/room temperature control (select one)</b> |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| At nominal heat output                                                                                                                                                                      | e <sub>l, max</sub>                                                         | N.A.                   | kW                                                                                 | Single-stage heat output, no room temperature control            |                  |                 |                                                                                     |      |        |                 | yes  |  |  |  |
| At minimum heat output                                                                                                                                                                      | e <sub>l, min</sub>                                                         | N.A.                   | kW                                                                                 | Two or more manual stages, no room temperature control           |                  |                 |                                                                                     |      |        |                 | no   |  |  |  |
| In standby mode                                                                                                                                                                             | e <sub>l, sb</sub>                                                          | N.A.                   | kW                                                                                 | With mechanic thermostat room temperature control                |                  |                 |                                                                                     |      |        |                 | no   |  |  |  |
| <b>Permanent pilot flame power requirement</b>                                                                                                                                              |                                                                             |                        |                                                                                    | With electronic room temperature control                         |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Pilot flame power requirement (if applicable)                                                                                                                                               | P <sub>pilot</sub>                                                          | N.A.                   | kW                                                                                 | With electronic room temperature control plus day timer          |                  |                 |                                                                                     |      |        |                 | no   |  |  |  |
|                                                                                                                                                                                             |                                                                             |                        |                                                                                    | With electronic room temperature control plus week timer         |                  |                 |                                                                                     |      |        |                 | no   |  |  |  |
|                                                                                                                                                                                             |                                                                             |                        |                                                                                    | <b>Other control options (multiple selection possible)</b>       |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
|                                                                                                                                                                                             |                                                                             |                        |                                                                                    | Room temperature control, with presence detection                |                  |                 |                                                                                     |      |        |                 | no   |  |  |  |
|                                                                                                                                                                                             |                                                                             |                        |                                                                                    | Room temperature control, with open window detection             |                  |                 |                                                                                     |      |        |                 | no   |  |  |  |
|                                                                                                                                                                                             |                                                                             |                        |                                                                                    | With distance control option                                     |                  |                 |                                                                                     |      |        |                 | no   |  |  |  |
| Contact details                                                                                                                                                                             | Barbas Bellfires BV<br>Hallenstraat 17<br>5531 AB BLADEL<br>The Netherlands |                        |                                                                                    |                                                                  |                  | www.barbas.com  |                                                                                     |      |        |                 |      |  |  |  |
| (*) PM = particulate matter, OGC = organic gaseous compounds, CO = carbon monoxide, NO <sub>x</sub> = nitrogen oxides<br>(**) Only required if correction factors F(2) or F(3) are applied. |                                                                             |                        |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Signed for and on behalf of the manufacturer by:<br>Danny Baijens, CEO                                                                                                                      |                                                                             |                        |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |
| Bladel; 20 August 2024                                                                                                                                                                      |                                                                             |                        |                                                                                    |                                                                  |                  |                 |                                                                                     |      |        |                 |      |  |  |  |

## 11 Warranty Terms

To make a claim under the warranty, it is important to register the Barbas appliance after purchase via [www.barbas.com](http://www.barbas.com).

### Barbas Warranty Terms

Barbas B.V. guarantees the quality of the supplied Barbas appliance and the quality of the materials used. All Barbas appliances are developed and manufactured according to the highest possible quality standards. If, despite all this, something should prove amiss with the Barbas appliance you have purchased, Barbas B.V. offers the following manufacturer's warranty.

#### Article 1: Warranty

1. If Barbas B.V. determines that the Barbas appliance you have purchased is defective as a result of a flaw in the construction or material, Barbas B.V. guarantees to repair or replace the appliance free of charge, without charging any costs for labor or spare parts.
2. Repair or replacement of the Barbas appliance will be undertaken by Barbas B.V. or by a Barbas dealer as designated by Barbas B.V.
3. This warranty is supplementary to the existing legal national warranty of Barbas dealers and Barbas B.V. in the country of purchase and is not intended to restrict your rights and claims based on the applicable legal provisions.

#### Article 2: Warranty conditions

1. Should you wish to claim under the warranty, please contact your Barbas dealer.
2. Complaints should be reported as quickly as possible after they have manifested themselves.
3. Complaints will only be accepted if they are reported to the Barbas dealer, together with the serial number of the Barbas appliance which is stated on the enclosed documents.
4. In addition, the original receipt (invoice, receipt, cash receipt) showing the date of purchase must also be submitted.
5. Repairs and replacements during the warranty period do not give any entitlement to an extension of the warranty period. After a repair or replacement of warranty parts, the warranty period shall be deemed to have started on the date of purchasing the Barbas appliance.
6. If a certain part is eligible for the warranty and the original part is no longer available, Barbas B.V. shall ensure that an alternative part of at least the same quality shall be provided.

#### Article 3: Warranty exclusions

1. The warranty on the Barbas appliance ceases to be in effect if:
  - a. it is not installed according to the installation instructions, and to national and/or local regulations;
  - b. it has been installed, connected or repaired by a non-Barbas dealer;
  - c. it has not be used or maintained according to the instructions for use;

- d. it has been changed, neglected or roughly treated;
- e. it has been damaged as a result of external causes (outside the appliance itself), for example, lightning strike, water damage or fire;
- 2. In addition, the warranty lapses if the original purchase receipt shows any change, deletion, removal or if it is illegible.

**Article 4: Warranty area**

- 1. The warranty is only valid in those countries where Barbas appliances are sold through an official dealer network.

**Article 5: Warranty period**

- 1. This warranty will only be granted during the warranty period.
- 2. The body of the Barbas appliance is guaranteed for a period of 10 years against construction and/or material faults, starting from the moment of purchase.
- 3. For other parts of the Barbas appliance, a similar warranty applies from the moment of purchase for a period of two years.
- 4. For user parts such as glass, glass sealing cord and the interior of the combustion chamber, a similar guarantee is given until after the first burning.

**Article 6: Liability**

- 1. A claim granted by Barbas B.V. under this warranty does not automatically imply that Barbas B.V. also accepts liability for any possible damage. The liability of Barbas B.V. never extends further than that stated in these warranty conditions. Any liability of Barbas B.V. for consequential damage is expressly excluded.
- 2. That stated in this provision is not valid if and to the extent that it derives from a mandatory provision.
- 3. All agreements entered into by Barbas B.V. are, unless specifically stated otherwise in writing and to the extent that they are permitted based on applicable law, subject to the FME-CWM general sales and delivery conditions for the technology industry.

Barbas B.V.  
Hallenstraat 17  
5531 AB Bladel  
The Netherlands

Email: [info@Barbas.com](mailto:info@Barbas.com)

Carefully retain the enclosed documents; they show the serial number of the appliance. You will need this if you wish to claim under the warranty.







# barbas .

Your Barbas dealer